


# CROSS - MIDI PRESET IMPLEMENTATION

## DENON - DN-SC2000



- |                                 |  |                                  |
|---------------------------------|--|----------------------------------|
| 1 - FX Unit                     | 11 - <i>not used</i>                     | 21.24 - Seek - <i>Vinyl/Bend</i> |
| 2 - Deck change                 | 12.17 - Pitch bend                       | 22 - PlayPause - <i>Cue Play</i> |
| 3 - FX Select                   | 13 - FX channel 1                        | 23 - Cue - <i>Set Cue</i>        |
| 4 - Expand/Collapse collection  | 14 - Pitch mode                          | 32 - Jog - <i>Browse</i>         |
| 5 - Change the active browsable | 15 - FX channel 2                        | 33 - Filter                      |
| 6 - FX Amount                   | 16 - Sync - <i>Match</i>                 | 34 - Select Cue                  |
| 7 - Browse                      | 18. 26 - Manual loop                     | 35 - Pitch                       |
| Load - <i>Preview</i>           | 27. 31 - Auto loop length                |                                  |
| 8 - FX Depth                    | 29 - Auto loop on/off                    |                                  |
| 9 - Change the active browsable | 19. 25. 28. 30 - Locators - <i>Clear</i> |                                  |
| 10 - Duplicate                  | 20 - Shift                               |                                  |