


**HERCULES – DJ CONSOLE 4-Mx**

**MIDI channels: 1-2; Deck mode: 2-Deck (extended); MIDI pitch resolution:14-bits**

- |                                     |                                   |                  |
|-------------------------------------|-----------------------------------|------------------|
| 5 – Pitch Range                     | 11.15 – Vinyl Mode                | 20 – Monitor Mix |
| 6 – Shift                           | 12 – Preview, ExpandCollapse Tree | 22 – Pitch Bend  |
| 7deckA&B – Locators - <i>delete</i> | 13 – Master Volume                | 23 – Pitch       |
| 7deckC&D – FX Select &On Off        | 14 – Browse the active browsable  |                  |
| <i>Autoloop</i>                     | 16 – Change the active browsable  |                  |
| 8 – Seek / Seek Length              | 17 – Gain                         |                  |
| 9 – Source                          | 18 – EQ                           |                  |
| 10 – Kill                           | 19 – FX Amount                    |                  |

1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24



- |                   |                   |               |
|-------------------|-------------------|---------------|
| 25 – Pitch Mode   | 29 – Load         | 34 – Cue Stop |
| 26 – Play Pause   | 31 – Crossfader   |               |
| 27 – Sync / Match | 32 – Volume Fader |               |
| 28 – Jog          | 33 – Headphones   |               |