

HERCULES - DJCONSOLE RMX2
(Velocities are disabled)

- | | |
|---|--|
| 1 Jog wheel with pressure detection | 19 Deck volume |
| 2 Fast-forward/rewind | 20 Crossfader |
| 3 Pitch Bend +/- | 21 Previewing on headphones and master |
| 4 Pitch fader | 22 Headphones volume |
| 5 XLR/6.35 mm (1/4") jack balanced microphone input | 23 6.35 mm (1/4") stereo headphones output |
| 6 Microphone volume | 24 Multifunctional pads (loops, effects, samples, cue points) |
| 7 Enable/disable microphone | 25 Multifunctional pads mode display |
| 8 Modulate effect amount or change active sample volume | 26 Multifunctional pads mode selection |
| 9 Enable source 1 (input 1-2) or source 2 (input 3-4) | 27 Switch the pads function: delete a Cue point (in Cue mode), change the pad playback mode (in Sample mode), change the loops length (in Loop mode) |
| 10 Deck's gain | Switch the knob function: modulate the effect depth (in Effects mode), change the samplers channels volume (in Sample mode) |
| 11 Master volume outputs 1-2 | Switch the Gain function: modulate the Filter |
| 12 Kill treble/medium/bass | 28 Synchronize deck |
| 13 Scratch mode enabled/disabled | 29 Cue point |
| 14 3-band equalizer | 30 Play/pause |
| 15 Files explorer | |
| 16 Load on deck A/deck B | |
| 17 Previewing on headphones | |
| 18 VU meter | |

