





Numark 4TRAK-FX MAPPING FOR CROSS DJ




1		SWITCH PLAY/SAMP C/D	SAMPLER
2		PAD 1 VOLUME	SAMPLER
2	+SHIFT	PAD 1 ROLLING FREQUENCY	SAMPLER
3		PAD 1 CONTROL	SAMPLER
3	+SHIFT	PAD 1 MODE	SAMPLER
4.1		PAD 2 VOLUME	SAMPLER
4.1	+SHIFT	PAD 2 ROLLING FREQUENCY	SAMPLER
4.2		PAD 3 VOLUME	SAMPLER
4.2	+SHIFT	PAD 3 ROLLING FREQUENCY	SAMPLER
4.3		PAD 4 VOLUME	SAMPLER
4.3	+SHIFT	PAD 4 ROLLING FREQUENCY	SAMPLER
5.1		PAD 2 CONTROL	SAMPLER
5.1	+SHIFT	PAD 2 MODE	SAMPLER
5.2		PAD 3 CONTROL	SAMPLER
5.2	+SHIFT	PAD 3 MODE	SAMPLER
5.3		PAD 4 CONTROL	SAMPLER
5.3	+SHIFT	PAD 4 MODE	SAMPLER

7		FILTER C	
7	+SHIFT	START/BRAKE TIME C	
6		FILTER C ON/OFF	
6	+SHIFT	RELOAD AS CLONE OF MASTER C	
7		FILTER A	
7	+SHIFT	START/BRAKE TIME A	
6		FILTER A ON/OFF	
6	+SHIFT	RELOAD AS CLONE OF MASTER A	
7		FILTER B	
7	+SHIFT	START/BRAKE TIME B	
6		FILTER B ON/OFF	
6	+SHIFT	RELOAD AS CLONE OF MASTER B	
7		FILTER D	
7	+SHIFT	START/BRAKE TIME D	
6		FILTER D ON/OFF	
6	+SHIFT	RELOAD AS CLONE OF MASTER D	



1	NOTHING
2	CROSSFADER CURVE
3C	CROSSFADER ASSIGN C (LEFT)
3A	CROSSFADER ASSIGN A (LEFT)
3B	CROSSFADER ASSIGN B (RIGHT)
3D	CROSSFADER ASSIGN D (RIGHT)

4	MONITOR VOLUME
5	NOTHING
6	CUE/MIX



23		DEFINE DOWNBEAT (BUTTON SET/DELETE)
23	+SHIFT	BEATGRID MOVE LEFT (BUTTON SET/DELETE)
23		BEATGRID EDIT ON/OFF (BUTTON MOVE)
23	+SHIFT	BEATGRID MOVE RIGHT (BUTTON MOVE)

1		NEEDLE SEARCH
2		TAP TEMPO / CONFIRM TAP TEMPO
3		LOOP HALVE / LOOP DOUBLE
4		SMART LENGHT
5		AUTOLOOP SELECT +/-
5	+SHIFT	SMART SEEK +/-
6		LOOP IN
7		LOOP OUT
7	+SHIFT	AUTOLOOP 2 BEAT
8 (AUTO)		LOOP ON/OFF
8 (AUTO)	+SHIFT	AUTOLOOP 8 BEAT
8 (AUTO 1)		AUTOLOOP 1 BEAT
8 (AUTO1)	+SHIFT	AUTOLOOP 16 BEAT
8 (AUTO 4)		AUTOLOOP 4 BEAT
8 (AUTO 4)	+SHIFT	AUTOLOOP 32 BEAT
9		SLIP MODE
10		VINYL ON/OFF
11		SET TO MASTER
12		PITCH RANGE
13 (FADER)		PITCH VALUE
13 (BUTTON)		PITCH BEND +/-
15		JOGWHEEL
16		SWITCH PLAYER A/C - B/D
17		BACK TO START
18		SHIFT
19		HOTCUE 1 TO 5
19	+SHIFT	DELETE HOTCUE 1 TO 5
20		SYNC
20	+SHIFT	MATCH BPM WITH MASTER
21		CUE
22		PLAY/PAUSE
22	+SHIFT	CUE-PLAY
24/25/26/27		GAIN/TREBLE/MIDDLE/BASS

11		SET TO MASTER (SAMPLER)	SAMPLER
13 (BUTTON)		CLOCK BEND UP/DOWN (SAMPLER C/D)	SAMPLER
13 (BUTTON)	+SHIFT	CLOCK UP/DOWN (SAMPLER C/D)	SAMPLER
20		SYNC WITH MASTER (SAMPLER C/D)	SAMPLER
20	+SHIFT	MATCH BPM WITH MASTER	SAMPLER
22		CLOCK/START STOP (SAMPLER C/D)	SAMPLER
29		CUE MONITOR A/B/C/D	
32		VOLUME A/B/C/D	
32	+SHIFT	FADER START A/B/C/D	
33		CROSSFADER	
9 (FADER)		FX AMOUNT	
9 (ROTARY)		FX SELECT	
9 (ROT)LEFT	+SHIFT	SNAP VALUE	
9 (ROT) RIGHT	+SHIFT	QUANTIZE VALUE	
9 (ROTARY)	+PUSH	FX ON/OFF	
9 (ROTARY)	+SHIFT+PUSH	FX INPUT CHANNEL + MASTER	
9 (ASSIGN 1)		AUDIO/VIDEO SWITCH FX1	
9 (ASSIGN 1)	+SHIFT	SNAP ON/OFF	
9 (ASSIGN 2)		AUDIO/VIDEO SWITCH FOR MIXER	
9 (ASSIGN 2)	+SHIFT	QUANTIZE ON/OFF	
9 (ASSIGN 3)		AUDIO/VIDEO SWITCH FX2	
9 (ASSIGN 3)	+SHIFT	SYNC LINK ON/OFF	
34		PITCH MODE	
34	+SHIFT	MATCH KEY WITH MASTER	
35		KEY SEMITONES	
36		LOAD A/B/C/D	
36	+SHIFT	EMPTY A/B/C/D	
37		CHANGE ACTIVE BROWSABLE = TREE	
38		CHANGE ACTIVE BROWSABLE = COLLECTION	
39		CHANGE ACTIVE BROWSABLE = NODEDOCK	
41		EXPAND/COLLAPSE COLLECTION	
41	+SHIFT	TOGGLE EXTERNAL DISPLAY	
42		FX INPUT CHANNEL A/B/C/D	
44		RECORD	
45		LIMITER	
45	+SHIFT	MIXER DISPLAY STATE MODE	
46	(+SHIFT)	BROWSE ACTIVE BROWSABLE + (VIDEO TRANSITION)	
46	+PUSH	PERFORM PRIMARY ACTION	
46	+SHIFT+PUSH	VIDEO TRANSITION = RESET = SCREEN	