


NUMARK – MIXTRACK PRO 2



- 1 – Browse / Preview / Expand / Collapse
- 2 – Load
- 3 – Change active browsable
- 4 – Shift
- 5 – Play Pause
- 6 – Cue Monitor
- 7 – Cue – *Set Cue*
- 8 – Jog
- 9 – Vinyl mode
- 10 – Pitch value – *Key semitones*
- 11 – Pitch bend - - *Pitch mode*
- 12 – Pitch bend + - *Pitch range*
- 13 – Sync – *Set as master*
- 14 – FX Amount
- 15 – FX Depth
- 16 – Loop In / Sample 1 / Locator 1
- 17 – Loop Out / Sample 2 / Locator 2
- 18 – Reloop / Sample 3 / Locator 3
- 19 – Loop /2 / Loop x2 / Sample 4 / Locator 4

- 20 – Fx Echo On/Off – *Autoloop 1*
- 21 – Fx Flanger On/Off – *Autoloop 2*
- 22 – Fx Roll On/Off – *Autoloop 4*
- 23 – Fx On/Off – *Autoloop 16*
- 24 – Volume Fader
- 25 – Master Volume
- 26 – Crossfader
- 27 – EQ High
- 28 – EQ Mid
- 29 – EQ Bass
- 30 – Cue Gain
- 31 – Cue Mix
- 32 – Cue Play
- 33 – FX Select
- 34 – FX Channel