


NUMARK – MIXTRACK PRO



- | | |
|--|---|
| 2 – EQ treble | 17 – Cue play |
| 3 – EQ mid | 18 – Cue |
| 4 – EQ basse | 19 – Sync / <i>Set as master</i> |
| 5 – Cue Monitor | 20 – Pitch value |
| 6 – Cue Gain | 21 – Pitch bend / <i>Key semitones</i> |
| 7 – Cue Mix | 22 – Master tempo |
| 8 – Browse / preview / expand / collapse | 23 – EQ kill |
| 9 – Change active browsable | 24 – View / Shift |
| 10 – Load / <i>Clone</i> | 25 – FX on off / <i>FX Input</i> |
| 11 – Volume fader | 26 – FX select |
| 12 – Master Volume | 27 – FX Amount / FX Depth |
| 13 – Crossfader | 28 – Manual loop [in / out / on-off] |
| 14 – Jog | Auto loop [divide beat / 1 bar / double beat] |
| 15 – Jog mode | |
| 16 – Play / Pause | |