


PIONEER – CDJ-350

(deck A: channel 1; deck B: channel 2; focus: channel 3)



- 11 – Play
- 10 – Cue
- 9 – Seek
- 8 – Seek lenght
- 14 – Loop in
- 15 – Loop out
- 16 – Loop
- 17 – Auto loop length

- 23 – Auto loop
- 27 – Pitch
- 26 – Pitch Mode
- 25 – Pitch Range
- 13 – Vinyl Mode
- 24 – Sync
- 22 – Browse / Load
- 21 – Preview

- 18/19 – Change the active browsable
- 2 – Select deck (focus mode)
- 12 – Jog