

PIONEER – CDJ-900

(deck A: channel 1; deck B: channel 2; focus: channel 3)



- | | | |
|-----------------|----------------------------|--|
| 1 – Play | 8 – Manual loop | 15 – Pitch Range |
| 2 – Cue | 9 – Jog | 16 – Vinyl Mode |
| 3 – Seek | 10 – Select Active Locator | 17 – Eject track or Select deck (focus mode) |
| 4 – Seek length | 11 – Clear Active Locator | 18 – Browse / Load |
| 5 – Reverse | 12 – Active Locator | 19 – Select |
| 6 – Beat Select | 13 – Pitch | 20 – Preview |
| 7 – Autoloop | 14 – Pitch Mode | |