


VESTAX - VCI-300/VCI-300MKII



- | | | |
|-------------------------------------|-------------------------------------|-----------------------------------|
| 1 – Pitch | 12 – EQ | 22 – Shift |
| 2 – Match / <i>Sync</i> | 13 – Auto loop divide / <i>Seek</i> | 23 – Headphones B / <i>Load B</i> |
| 3 – Pitch mode / <i>Pitch reset</i> | 14 – Master level | 24 – Browse |
| 4 – Pitch range | 15 – Cue mix | 25 – Jogs / <i>Browse</i> |
| 5/7 – Locators / <i>Clear</i> | 16 – Monitor level | 26 – Browse Node |
| 6 – Scratch | 17 – Cue | 27 – Browse Tracks |
| 8 – Shift | 18 – Play-pause | 28 – Browse Tree |
| 9 – Gain | 19 – Crossfader | |
| 10 – Slip mode / <i>Reverse</i> | 20 – Volume | |
| 11 – Autoloop on/off | 21 – Headphones A / <i>Load A</i> | |