


VESTAX - VCI-100MKII



- 1 - FX Select / FX Amount / FX Depth / Brake
- 2 - Locators
- 3 - Pitch mode - *Loop *1/2*
- 4 - Loop On Off - *Loop *2*
- 5 - Seek - *Seek length*
- 6 - Sync - *Match*
- 7 - Not used
- 8 - Pitch

- 9 - Shift
- 10 - Fx On Off
- 11 - Filter
- 12 - Jog
- 13 - Play/Pause - *Pad1*
- 14 - Cue - *Pad2*
- 15 - Slip mode On Off - *Pad3*
- 16 - Vinyl Mode - *Pad4*
- 17 - EQ

- 18 - Not used
- 19 - Gain
- 20 - FX Channel
- 21 - Monitor
- 22 - Select Channel
- 23 - Browse / Preview / Expand
- 24 - Volume
- 25 - Crossfader