


VESTAX - VCI-380



No.	Control name	Function		
		Direct	Shift +	Jog Scroll +
2	Ribbon (strip) control	Needle search	-	-
3	Pads	1-4 : Locators	Clear locators	-
4	Pad FX encoder	Autoloop	-	-
5	FX control area	Amount	-	-
		Select / Routing	-	-
		FX on/off	-	-
6	Pitch slider	Pitch value	-	-
7	Range / Keylock	Pitch range	Pitch mode	-
8	Shift button	-	-	-
9	Jog wheel	Scratch / bend	Seek	Navigate section
12	Vinyl button	Jog mode	Sampler link	-
13	Transport buttons	Cue / Play	-	-
14	Sync button	Sync player to	Sync sampler to	-
15	Crossfader	Crossfader	-	-
16	Input fader	Volume	-	-
19	Channel trim	Gain	-	-
20	Channel EQ	EQ	-	-
22	Browsing area	Area : Prepare	-	-
		View : Expand collection	-	-
		Sort : Track collection	-	-
		Back/Fwd : Change section	-	-
		Scroll : Navigate section	-	-
		Tab : Execute action	-	-
23	Cue selector area	Cue : monitoring	-	Load track
25	Crossfader curve adjust	crossfader curve adjust	-	-
27	Cue mix adjustment	cue monitor mix	-	-